TEMPORARY STRAND CUTTING SEQUENCE

- 1. ERECT AND BRACE GIRDERS.
- 2. REMOVE EXPANDED POLYSTYRENE IN 2" x 6" RECESSES IN TOP FLANGE OF GIRDERS.
- 3. CUT STRANDS IN 2" x 6" RECESSES. STRANDS MAY BE CUT BY USING A CUTTING TORCH AND MOVING THE FLAME BACK AND FORTH OVER THE LENGTH OF EXPOSED STRAND TO LET INDIVIDUAL WIRES BREAK ONE AT A TIME TO LESSEN THE SHOCK TO THE GIRDER. STRANDS SHALL BE RELEASED IN A SYMMETRICAL MANNER AROUND THE GIRDER CENTERLINE STARTING WITH THOSE NEAREST THE CENTERLINE AND WORKING OUTWARDS.
- 4. REMOVE ALL MOISTURE IN RECESS PRIOR TO FILLING RECESS WITH GROUT.

BRIDGE AND STRUCTURES OFFICE



MULTIPLE SPAN PRESTRESSED GIRDER
CONSTRUCTION SEQUENCE

SHETT

SHEET NO:

Thu Oct 18 10:37:37 2012

5.6-A2-